



## Parts List for DWE4120 Type 1

Item Number	Part Number	Description	Qty Required
3	N232477	ARMATURE ASSEMBLY	1
4	N122021	END HANDLE	1
5	N232486	PADDLE ASSY.	1
6	N167538	SWITCH	1
8	N097696	BRUSH	2
12	N017839	SCREW	1
13	562097-00	SCREW	1
14	619328-00	CLAMP	1
15	330005-01	PROTECTOR,CORD	1
16	N042786	GUARD	1
16	N105312	GUARD	1
17	330065-31	SCREW	4
18	330072-98	CORD/8FT/18-2SJ	1
19	N124292	LOCK-ON BUTTON	1
20	N115381	CLAMP WASHER	1
21	N134467	HEX HOLE FLANGE	1
22	N136731	GUARD LEVER RELEASE	1
23	N137733	SHOULDER SCREW	1
24	N105579	SPRING	1
25	N135116	SPRING WASHER	1
26	593478-00	SCREW	2
28	N149175	ID LABEL	1
31	604484-00	NUT	1
32	N153125	PINION	1
33	N175104	BALL BEARING	1
34	N132042	OPP STATOR	1
36	N101228	SLINGER	1

## Parts List for DWE4120 Type 1

Item Number	Part Number	Description	Qty Required
37	N130916	BALL BEARING	1
38	641823-00	BEARING CUP	1
39	N213812	SLINGER	1
41	N122019	FIELD CASE	1
42	N232485	FIELD	1
43	N167600	BRUSH BOX	1
44	N132864	BAFFLE	1
45	N097702	BRUSH BOX ASSY	1
46	N097703	BRUSH SPRING	2
49	N130031	SCREW STOP	1
51	N153391	GEAR CASE	1
52	N181764	SPINDLE ASSY.	1
53	N153126	GEAR	1
54	330003-64	BALL BEARING	2
55	N094024	O-RING	1
56	N118088	SCREW, SHOULDER	3
57	N094651	WASHER	1
58	N092954	COMPRESSION SPRING	1
59	N126708	RUBBER PLUG	1
60	444793-00	RING, RETAINING	1
62	N122904	SCREW	4
63	N232837	GEAR CASE COVER	1
64	N119639	O-RING	1
65	N094012	O-RING	1
67	N181767	SPINDLE LOCK ASSY.	1
73	N095815	SPACER	1
74	638229-00	SLINGER	1

## Parts List for DWE4120 Type 1

Item Number	Part Number	Description	Qty Required
75	N119716	WARNING LABEL	1
80	N239381	SIDE HANDLE	1
81	N107295	HEX WRENCH	1
85	444262-00	TERMINAL	2
86	330065-25	SCREW	4
87	562210-00	SPRING	2
90	N260662	SPRING	1
800	30301914-01	GREASE	1
800	429954-01	GREASE, 500GRAMS	1
800	429954-00	GREASE, 7LBS	1