



## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
1	5140147-55	SCREW	1
2	5140147-56	PRESSURE BOARD	1
3	5140147-57	SWITCH BOX	1
4	5140147-58	SCREW	8
5	5140147-59	OVERLOAD SWITCH	1
6	5140147-60	SWITCH	1
7	5140147-61	SCREW	2
8	5140160-22	LABEL	1
9	5140147-63	LOCK NUT	2
10	5140147-64	HAND WHEEL	1
11	5140146-75	FLAT WASHER	13
12	5140147-65	HANDLE	1
13	5140147-66	FLAT WASHER	2
14	5140147-67	SCREW	1
15	5140147-68	COILING HOOK	2
16	5140147-69	POINTER,ANGLE	2
17	5140146-50	SCREW	2
18	5140147-70	LOCK NUT	6
19	5140147-71	SCREW	4
20	5140147-72	GEAR RACK	1
21	5140147-73	SCREW	3
22	5140147-36	SCREW	11
23	5140147-74	POINTER	1
24	5140146-14	SPRING WASHER	5
25	5140147-75	NUT	7
26	5140147-76	WASHER	4
27	5140160-23	BODY	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
28	5140147-78	SCREW	1
29	5140147-79	SCREW	8
30	5140147-80	FLAT WASHER	4
31	5140147-81	GUIDE BLOCK	1
32	5140147-82	WASHER	2
33	5140147-83	NUT	1
34	5140147-84	TORSION SPRING	1
35	5140147-85	PIN	1
36	5140151-45	AXIS	1
37	5140147-87	SCREW	1
38	5140151-46	PRESSURE HANDLE	1
39	5140147-89	RING	1
40	5140147-90	WASHER	1
41	5140147-91	SCREW	1
42	5140147-92	AXLE SLEEVE	1
43	5140147-93	GUIDE BLOCK	1
44	5140147-94	AXLE SLEEVE	1
45	5140147-95	FASTEN BAR	1
46	5140147-96	SCREW	10
47	5140147-97	GEAR WHEEL	2
48	5140147-98	SCREW	2
49	5140147-99	POINTER SEAT	1
50	5140148-00	SUPPORT	1
51	5140151-47	SCREW	3
52	5140148-01	ROTATION BAR	1
53	5140148-02	SCALE	1
54	5140148-03	FLAT WASHER	8

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
55	5140148-04	SCREW	4
56	5140148-05	SUPPORT BAR	1
57	5140148-06	SCREW	2
58	5140148-07	GUARD	1
59	5140148-08	PRESSURE BOARD	2
60	5140148-09	WASHER	4
61	5140148-10	ROTATE SUPPORT	1
62	5140151-47	SCREW	1
63	5140148-12	BRACKET	1
64	5140148-13	SPRING WASHER	4
65	5140148-14	SCREW	2
66	5140146-24	LOCK NUT	2
67	5140148-15	FLAT WASHER	3
68	5140148-16	LOCATOR BLOCK	1
69	5140148-17	COVER BLOCK	1
70	5140151-49	NUT	1
71	5140148-19	OUTER FLANGE	1
73	5140151-51	INNER FLANGE	1
74	5140148-21	BEARING HOUSING	1
75	5140148-22	BEARING	1
76	5140148-23	SNAP RING	1
77	5140148-24	OUTPUT AXIS	1
78	5140148-25	KEY	1
79	5140148-26	GEAR WHEEL	1
80	5140148-27	CIRCLIP	1
81	5140148-28	NEEDLE BEARING	1
82	5140148-29	COVER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.

## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
83	5140146-31	LOCK NUT	1
84	5140148-30	WASHER	3
85	5140148-31	BEARING	1
86	5140148-32	THREADED ROD	1
87	5140148-33	ARMATURE	1
88	5140148-34	BEARING	1
89	5140148-35	SCREW	2
90	5140148-36	FIELD	1
91	5140148-37	SHROUD	1
92	5140148-38	MOTOR HOUSING	1
93	5140148-39	BRUSH HOLDER	2
94	5140148-40	BRUSH	2
95	5140148-39	BRUSH HOLDER	2
96	5140148-42	SCREW	3
97	5140145-99	SPRING WASHER	3
98	5140148-43	FLAT WASHER	3
99	5140148-44	KNOB	1
100	5140148-45	WASHER	2
101	5140148-46	ANGLE BOARD	1
102	5140148-47	PIN	1
103	5140148-48	SQUARE NUT	1
104	5140148-49	FENCE COVER	1
105	5140148-50	HANDLE	1
106	5140148-51	ALLOY	1
107	5140148-52	FENCE COVER	1
108	5140148-53	FENCE	1
109	5140148-54	PIN	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.

## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
110	5140148-55	SPRING	1
111	5140148-56	CIRCLIP	2
112	5140148-57	SCREW	3
113	5140148-58	SCREW	1
114	5140148-59	PRESSURE BOARD	1
115	5140148-60	ANTI-KICKBACK	1
116	5140148-61	LOCATOR	2
117	5140148-62	SPRING	1
118	5140148-63	PRESSURE BOARD	1
119	5140148-64	GUARD	1
120	5140148-65	COVER	1
121	5140148-66	WASHER	1
122	5140148-67	GUARD	1
123	5140148-68	PROTECTIVE BOARD	1
124	5140148-69	SPACER	1
125	5140148-70	GUARD	1
126	5140148-71	SPRING	1
127	5140148-72	PIN	1
128	5140148-73	RIVING KNIFE	1
129	5140148-74	SCREW	4
130	5140148-75	PUSH STICK	1
131	5140148-76	PLATE	1
132	5140148-77	PLATE	1
133	5140148-78	CLAMP SCREW	1
134	5140146-38	HOLLOW PIN	1
135	5140148-79	KNOB	1
136	5140146-89	FLAT WASHER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
137	5140148-80	LOCK HANDLE	1
138	5140148-81	NUT	1
139	5140148-82	PIN	1
140	5140148-83	WHEEL	1
141	5140148-84	BOARD	1
142	5140148-85	TABLE	1
143	5140148-86	SCALE	1
144	5140148-87	LOCKING PLATE	1
145	5140148-88	PIN	1
146	5140148-89	ROD	1
147	5140148-90	PIN	1
148	5140148-91	LOCK NUT	1
149	5140148-92	MAGNIFIER	1
150	5140148-93	FENCE HEAD	1
151	5140148-94	WASHER BOARD	1
152	5140148-95	WASHER	1
153	5140148-96	SCREW	1
154	5140148-97	FENCE	1
155	5140148-98	BACK BOARD	1
156	5140148-99	SPRING	1
157	5140149-00	STEEL PLATE	1
158	5140149-01	WASHER	1
159	5140167-85	KERF PLATE	1
160	5140149-03	CLAMP	1
161	5140149-04	CLAMP	1
162	5140147-33	SCREW	4
163	5140149-05	SCREW	4

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
164	5140149-06	SPRING BLOCK	1
165	5140149-07	ANGLE BOARD	1
166	5140149-08	CORD PROTECTOR	1
167	5140147-14	CORD SET	1
168	5140149-09	LOCK NUT	1
169	5140149-10	CIRCLIP	4
170	5140149-11	SCREW	4
171	5140149-12	ROLL PIN	4
172	5140149-13	SHAFT	2
173	5140149-14	WHEEL	2
174	5140149-15	CABLE	1
180	5140153-01	SPACER	1
181	5140153-02	WRENCH	1
182	5140153-03	HEX WRENCH	1
183	5140153-04	HEX WRENCH	1
184	5140160-24	LABEL	1
190	5170019-06	MITER GAUGE ASM	1
191	5170019-07	GUARD ASSEMBLY	1
192	5170019-08	PAWL ASSY.	1
193	5170019-09	FENCE ASSEMBLY	1
201	5140151-52	BRACKET	2
202	5140149-17	NUT	28
203	5140149-18	BOLT	24
204	5140151-53	BRACKET	2
205	5140151-54	BRACKET	2
206	5140151-55	BRACKET	1
207	5140151-56	STAND BAR	4

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.



## Parts List for STST1825-B3 Type 1

Item Number	Part Number	Description	Qty Required
208	5140149-23	FOOT	4
209	5140149-24	HEX BOLT	4
210	5140149-25	FLAT WASHER	4
211	5140148-81	NUT	4
301	5140149-26	SCREW	6
302	5140149-27	EXTENSION BAR	2
303	5140146-84	SCREW	8
304	5140149-28	SPRING WASHER	8
305	5140146-06	SCREW	4
306	5140149-30	GUIDE	2
307	5140149-31	SCALE	1
308	5140149-32	EXTENSION TABLE	1
309	5140149-33	SCREW	2
310	5140149-34	HANDLE	1
312	5140153-06	EXTENSION BAR	2
313	5140148-27	CIRCLIP	4
314	5140149-27	EXTENSION BAR	1
315	5140147-80	FLAT WASHER	8

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.